

1800 W. McCormick Road Amarillo, TX 79118

1-800-SEWFINE

Phone (806) 622-5103 • Fax (806) 622-5104

e-mail: sewfineproducts@msn.com

www.sewfineproducts.com

**SEWFINE INTERIOR
PRODUCTS
SEAT COVER
INSTALLATION GUIDE**

SEWFINE INTERIOR PRODUCTS

SEAT COVER INSTALLATION

TOOLS AND ACCESSORIES REQUIRED

1. CRESCENT WRENCH/ 5/16 ALLEN WRENCH
2. HOGRING KIT
3. SEAT PAD CUSHIONS
4. SISEL SPRING COVER (BURLAP)
5. SPRAY ADHESIVE
6. SPRAY PAINT
7. SCISSORS
8. HAMMER
9. SCREW DRIVER

SEAT REMOVAL

BUG 1949-1979

1949-1971- Pull up adjusting lever and slide seat forward. 1972-Pull up adjusting lever and slide seat forward. On the right hand side of the seat, there is a metal tab that must be pushed down with a screw driver to slide the seat completely out of the car. 1973-1979 Remove black caps at the end floor tracks. Slide the seat back while holding down the metal safety latch located underneath the front of the seat.

GHIA ALL YEARS

~~Pull up adjusting lever and slide seat forward.~~

BUS 1950-1979

1950-1976-Pull up adjusting lever and slide seat forward.

BUS CONT.

1977-1979- Pull up adjusting lever and slide seat forward. On the right side of the seat, there is a metal tab that must be pushed down with a screw driver to slide the seat completely out of the car.

TYPE 3'S 1964-1974-Sq.back, Fastback, and Notchback

1964-1972- Pull up adjusting lever and slide seat forward. On the right hand side of the seat, there is a metal tab that must be pushed down with a screw driver to slide the seat completely out of the car. 1973-1974- remove black caps at the end of the floor tracks. Slide the seat back while holding down the metal safety latch located underneath the front of the seat.

WATER COOLED MODELS

Remove black caps at the end of the floor tracks. Slide the seat back while holding down the metal safety latch located underneath the front seat.

SEAT INSTALLATION

1. Remove seats from car.
2. Disassemble backrests from seat bottom by using a Crescent Wrench(54-72 models) or a 5/16 inch Allen Wrench for (73-76 models). Remove the clip on (77-up models).

Note: Type II Bus (56-76 models) the front backrest is riveted to the seat and cannot be removed.

3. Strip old upholstery (buttons 68-72 models) and padding off frames. Save padding and metal rod if reusable. Sand and paint frames if desired.
4. Install Burlap over sisel springs allowing 3" around the perimeter of the frame to wrap Burlap around outer edges and hogring down.
5. Install padding over the sisel. If old padding is not reusable, we recommend using Sewfine's High density form fitted Polyurethane foam.
6. Vinyl upholstery can be placed in the sun until pliable. Do not put in dryer.
7. (INSTALLATION OF SEATCOVERS)- Align seat cover evenly around the edge. Begin by pulling the front over from left to right until cover is completely over the frame. (CAUTION!!!!- support seams when installing covers) turn over and insert the metal rod into slot then pull draw strings and tie to frame. Attach the cover to the existing hooks, making sure to keep the string to the outside of hood for strength. After attaching, bend over hooks with hammer. NOTE: If stock hooks are broken, then hogrings must be used. Repeat these procedures for all remaining seats.
8. (INSTALLATION OF BACKREST COVERS)-Begin by placing plastic wrap over the top and around the foam. This will make it easier to slip on the covers. Align cover evenly along the edge of the foam and pull down on each side a little at a time until cover is completely installed. (Caution!!!!-Support seams when installing covers). Insert the metal rods into the slots. ~~First attach the front insert and then the rear.~~ Bend over tabs towards the front of the seat. (Install buttons if applicable).